

POPPING INSTRUCTIONS:

1. TURN ON BOTH SWITCHES



2. LIFT LID, PUT 1 SCOOP COCONUT OIL IN KETTLE AND WAIT UNTIL IT MELTS



3. ADD IN 1 SCOOP FLAVACOL



4. ADD IN 3 SCOOPS OF KERNELS, CLOSE LID



X 3

5. WAIT UNTIL POPCORN POPS WITH 3-5 SECOND GAPS



6. SHUT KETTLE OFF, LIFT LID, DUMP KETTLE (ARM TWISTS)

7. LEAVE POWER SWITCH ON TO KEEP ANY EXTRA POPCORN WARM

ENJOY

KETTLE CORN: ADD **HALF** AS MUCH GLAZE AS POPCORN (INSTEAD OF FLAVOCOL). **FOR EXAMPLE:** 3 CUPS POPCORN = 1 1/2 CUPS GLAZE

BUTTER TOPPING: PUMP HANDLE ON **MISTER** 10-15 TIMES, SPRAY ON POPCORN WHILE FILLING BOWL (REFILL MISTER WITH FLAVORING UP TO **1/2 FULL**)